

INSTALLATION INSTRUCTIONS FOR OUTSIDE ACCESS PANEL FRAME KIT P/N 4691


1. Mark a 12-1/2" x 50-1/4" opening on booth panel where fixture is to be located.
2. Cut opening in booth panel using suitable tools.
3. Install panel frames (Item #6 and Item #7) into opening in panel as shown in detail A-1.
4. Install corner brackets (Item #5) to each corner where panel frames meet. Drill 1/8" holes through corner brackets and panel frames and pop rivet in place using 1/8" pop rivets included with installation kit.
5. To install glass lens into panel frame:
 - A. Install 1/2 x 3/4 closed cell gasket (Item #1) around perimeter of panel frame as shown in detail A-1.
 - B. Install tempered glass lens (Item #4) into panel frame and lock into place using glass clips (Item #3) and 1/4 - 20 bolts and nuts as shown in detail A-1.
6. Install light fixture into panel frame and lock into place using (4) light clips (Item #2) and 1/4 - 20 bolts and nuts.
7. Installation is now complete and fixture is ready to be wired into service.

NOTE: See wiring diagram on back of ballast for proper wiring.

8. This fixture should be installed by qualified technicians in strict accordance with the National Electrical Code and any local requirements.

390240 - 390226 FLUORESCENT LIGHT FIXTURE

Note: See Installation Instructions on back




INSTALLATION KIT

(P/N 4691)

Item	Description	Qty.
1	1/2" x 3/4" Closed Cell Gasket.....	12
2	Light Clip - 240 P/N 4693	4
3	Glass Clip P/N 4695	2
*4	Clear Tempered Glass 3/16"x15"x53"	1
5	1-1/2" x 1-1/2" Corner Bracket 4696	4
6	Frame (15-3/4" Long) 4697	2
7	Frame (53-1/2" Long) 4698	2
8	1/8" Pop Rivet 3125	8
9	1/4 - 20 Unc. x 3/4" Bolt & Nut	10
	Installation Sketch	1

*Note: Item 4 (P/N 1706) is optional
NOT INCLUDED IN KIT.



WIRE PER DIAGRAM ON BALLAST.

Title: 390240 - 390226 Fluorescent Light Fixture
Outside Access Kit (P/N 4691)